

Always there to help you

Register your product and get support at
www.philips.com/welcome

AC4025



EN	User Manual	3
----	-------------	---

TH	คู่มือผู้ใช้	19
----	--------------	----

PHILIPS

Contents

1 Important	
Safety	4
2 Your air purifier	5
What's in the box	5
3 Get started	6
Install filters	6
4 Use the air purifier	8
Understand the healthy air protect alert	8
Switch on or off	8
Change the fan speed	9
Sleep mode	9
Set the Timer	10
5 Clean your air purifier	11
Clean the air purifier	11
Clean the activated carbon filter	11
6 Replace the filters	13
Replace the activated carbon filter and the HEPA filter	13
Reset the filter lifetime counter	15
7 Troubleshooting	16
8 Guarantee and service	17
Order parts or accessories	17
9 Notices	18
Electromagnetic fields (EMF)	18
Compliance with EMF	18
Recycling	18

1 Important

Safety

Read this user manual carefully before you use the appliance, and save it for future reference.

Danger

- Do not let water or any other liquid or flammable detergent enter the appliance to avoid electric shock and/or a fire hazard.
- Do not clean the appliance with water; any other liquid, or a (flammable) detergent to avoid electric shock and/or a fire hazard.

Warning

- Check if the voltage indicated on the bottom or indicated at the rear of the appliance corresponds to the local power voltage before you connect the appliance.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons in order to avoid a hazard.
- Do not use the appliance if the plug, the power cord, or the appliance itself is damaged.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and maintenance shall not be made by children without supervision.
- Do not block the air inlet and outlet, e.g. by placing items on the air outlet or in front of the air inlet.

Caution

- This appliance is not a substitute for proper ventilation, regular vacuum cleaning, or use of an extractor hood or fan while cooking.
- If the power socket used to power the appliance has poor connections, the plug of the appliance becomes hot. Make sure

that you plug the appliance into a properly connected power socket.

- Always place and use the appliance on a dry, stable, level, and horizontal surface.
- Leave at least 20cm free space behind and on both sides of the appliance and leave at least 30cm free space above the appliance.
- Do not place anything on top of the appliance and do not sit on the appliance.
- Do not place the appliance directly below an air conditioner to prevent condensation from dripping onto the appliance.
- Make sure all filters are properly installed before you switch on the appliance.
- Only use the original Philips filters specially intended for this appliance. Do not use any other filters.
- Avoid knocking against the appliance (the air inlet and outlet in particular) with hard objects.
- Always lift or move the appliance by the handle at the back of the appliance.
- Do not insert your fingers or objects into the air outlet.
- Do not use this appliance when you have used indoor smoke-type insect repellents or in places with oily residues, burning incense, or chemical fumes.
- Do not use the appliance near gas appliances, heating devices or fireplaces.
- Always unplug the appliance after use and before you clean it.
- Do not use the appliance in a room with major temperature changes, as this may cause condensation inside the appliance.
- To prevent interference, place the appliance at least 2m away from electrical appliances that use airborne radio waves such as TVs, radios, and radio-controlled clocks.
- The appliance is only intended for household use under normal operating conditions.
- Do not use the appliance in wet surroundings or in surroundings with high ambient temperatures, such as the bathroom, toilet, or kitchen.
- The appliance does not remove carbon monoxide (CO) or radon (Rn). It cannot be used a safety device in case of accidents with combustion processes and hazardous chemicals.

2 Your air purifier


Congratulations on your purchase, and welcome to Philips!

To fully benefit from the support that Philips offers, register your product at www.Philips.com/welcome.

Read this user manual carefully before you install and use the unit. Save it for future reference.

What's in the box

Check and identify the contents of your package:



Filter 4: HEPA filter
(AC4104)

Filter 3: Activated carbon filter
(AC4103)

Filter 1 and 2 are for other Philips air purifier.



User manual



Warranty



Quick start guide

3 Get started

Install filters

The air purifier comes with all filters fitted inside, but you have to remove the packaging of the filters before you can use the appliance. Remove all filters, unpack them, and place them back into the air purifier as described below.



Tip


- When you remove or insert filters, place the air purifier against a wall for more stability.




Note

- Insert the filters in the correct position.


- 1 Place your fingers at the top panel and gently pull the top part of the front panel towards you. (1)
- 2 Lift the panel out of the hooks at the bottom of the purifier. (2)




- 3 Remove all the filters from the purifier.



- 4 Remove all packaging material from the filters.




- 5 Put the filters back into the purifier.



Note

- Make sure that the side with the tag is pointing towards you, and the tag is at the bottom end of the filter.


- 6 To reattach the front panel, insert the bottom hooks into the bottom of the purifier first (1). Then, push the panel against the body of the purifier (2).





4 Use the air purifier

Understand the healthy air protect alert


This purifier is equipped with the Healthy air protect alert to make sure that the filters are in optimal condition when the purifier is operating.



The filter replacement light () indicates the filter have to be replaced.


Healthy air protect alert	Follow this
Filter replacement light  flashes. This lasts approximately for 2 weeks.	You still have 2 weeks time to replace the activated carbon filter and the HEPA filter.
Filter replacement light  is on continuously.	Replace the activated carbon filter and the HEPA filter immediately.


Switch on or off


- 1 Plug the air purifier into the power socket.
↳ All lights go on twice. Then, the lights go out again.



- 2 Press the  button to switch on the purifier.
↳ The power-on light [] on the control panel goes on.



- 3 Press the  button to switch off the purifier.



Change the fan speed


You can select the desired fan speed.




Note

- When you select a fan speed, you can also use the timer function (see "Set the timer"). In this case, one of the Ⓛ lights (1, 4, or 8) and the one of the Ⓢ lights (☼, ~, or ≈) are on.

- Press the Ⓢ button to switch on the purifier.




- Press the Ⓢ button once or more times to select the desired fan speed (☼, ~, or ≈).




Sleep mode

In sleep mode, the air purifier operates very quietly for your undisturbed sleep.

- Press the Ⓢ button to switch on the air purifier.



- Press the Ⓢ button to select sleep mode.
→ The ☼ light goes on while the Ⓢ goes off.



To change to another fan speed, press the Ⓢ button.

Set the Timer


With the timer function, you can let the purifier operate for a set number of hours.

When the set time has elapsed, the purifier automatically switches off.


You can use the timer function in the following situation:

Situation	You will see
Choose a fan speed manually (see 'Manual')	One of the ☼ lights (☼, ☼, or ☼) and one of the ☼ lights (1, 4, or 8) are on.

- 1 Press the ⏻ button to switch on the purifier.



- 2 Press the ⏻ button to activate the timer.
↳ The ☼ light (1, 4, or 8) goes on.



- 3 Press the ⏻ button repeatedly to choose the number of hours you want the purifier to operate. The corresponding ☼ light (1, 4, or 8) goes on.

To deactivate the timer function, press the ⏻ button repeatedly until the ☼ light (1, 4, or 8) is out.

5 Clean your air purifier



Note

- Always unplug the purifier before you clean it.
- Never immerse the purifier in water or any other liquid.
- Never use abrasive, aggressive, or flammable cleaning agents such as bleach or alcohol to clean any part of the purifier.
- The air purifier filters are not washable.

Clean the air purifier

Regularly clean the inside and outside of the purifier body to prevent dust from collecting.

- 1 Wipe away dust with a soft dry cloth from the body of the purifier.
- 2 Clean the air inlet and the air outlet with a soft dry cloth.

Clean the activated carbon filter


This activated carbon filter catches large airborne particles like lint, dust, human hair, and pet hair. It also helps remove odors.




Note

- The activated carbon filter is not washable nor vacuum cleanable.
- Clean the activated carbon filter for every two weeks to ensure optimal functioning of the purifier.


- 1 Switch off the purifier and unplug it.




- 2 Place your fingers at the top panel and gently pull the top part of the front panel towards you (1). Lift the panel out of the hooks at the bottom of the purifier (2).




- 3 Remove the activated carbon filter.




- 4 Clean the activated carbon filter with soft brush to remove dust.




- 5 Put the activated carbon filter back into the purifier.



- 6 To reattach the front panel, insert the bottom hooks into the bottom of the purifier first (1). Then, push the panel against the body of the purifier (2).




6 Replace the filters


The filter replacement light () indicate the filter have to be replaced.


Replace the activated carbon filter and the HEPA filter


Note

- The activated carbon filter and the HEPA filter are neither washable nor vacuum cleanable.


Replace both the activated carbon filter and HEPA filter when the  light starts to flash. This will last for approximately 2 weeks. When you do not replace the filter in time:

↳ The  lights up continuously.



In sleep mode, when the  light starts to flash but dim, replace both the activated carbon filter and HEPA filter. This will last for approximately 2 weeks.

When you do not replace the filter in time:

↳ The  lights up but dim continuously.


Tip

- When you remove or insert filters, place the purifier against a wall for more stability.


Note

- Insert the filters in the correct position.
- Make sure you place the filters in the order of HEPA filter and activated carbon filter.
- Make sure that the side with the tag is pointing towards you, and the tag is at the bottom end of the filter.


1 Switch off the purifier and unplug it.



2 Place your fingers at the top panel and gently pull the top part of the front panel towards you (1). Lift the panel out of the hooks at the bottom of the purifier (2).




- 3 Remove the filters using the tag on the filter. Take the filters by both sides and gently deposit them into the household trash bin.




Note

- Do not touch the pleated filter surface, or smell the filter as it has collected pollutants from the air.
- Wash your hands after disposing of the used filters.


- 4 Remove all packaging material from the new filters.




- 5 Place the new HEPA filter in the purifier first.



- 6 Place the new activated carbon filter in the purifier.



- 7 To reattach the front panel, insert the bottom hooks into the bottom of the purifier first (1). Then, push the panel against the body of the purifier (2).




- 8 Reset the activated carbon filter and the HEPA filter lifetime (see 'Reset the filter lifetime counter').

Reset the filter lifetime counter


When you replace the filters, it is important that you also reset the filter lifetime counter afterwards. This allows the purifier to be in sync with the filter lifetime.


After you have replaced the filter, reset the filter time:


- 1 Switch off the purifier and unplug it.




- 2 Replace the air purifier filter (see 'Replace the filters').
- 3 Put the plug in the power socket and switch on the purifier again.



- 4 Press and hold the  button for 2 seconds.






Note

- Reset the purifier when it is plugged in and switched on.
- Only replace the filters when you see the  light start flashing.

7 Troubleshooting

This chapter summarizes the most common problems you could encounter with the purifier. If you are unable to solve the problem with the information below, contact the Consumer Care Center in your country.

Problem	Possible solution
The  light has been flashing.	The filter is full. Replace the filter and reset the purifier.
No air comes out of the air outlet.	The purifier is not connected to the power supply. Plug the purifier into the power socket and switch on.
The airflow that comes out of the air outlet is significantly weaker than before.	Please check if you have removed all the packaging material from the filters.
The air quality does not improve, even though the purifier has been operating for a long time.	One of the filters has not been placed in the purifier. Make sure that all filters are properly installed in the following order, starting with the innermost filter: 1) HEPA filter; 2) activated carbon filter.
The purifier is extra loud.	<ul style="list-style-type: none">• Please check if you have removed all the packaging material from the filters.• If the appliance is still too loud, you can change the fan speed to a lower fan speed level.
The purifier still indicates that I need to replace a filter, but I already did.	Perhaps you did not press the filter reset button properly. Plug in the purifier; press the  button. Then, press and hold the  button for 2 seconds.

8 Guarantee and service

If you need information or if you have a problem, please visit the Philips website at www.philips.com or contact the Philips Consumer Care Center in your country (you can find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

Order parts or accessories

If you have to replace a part or want to purchase an additional part, go to your Philips dealer or visit www.philips.com/support. If you have problems obtaining the parts, please contact the Philips Consumer Care Center in your country (you find its phone number in the worldwide guarantee leaflet).

9 Notices

Electromagnetic fields (EMF)

This Philips appliance complies with all applicable standards and regulations regarding exposure to electromagnetic fields.

Compliance with EMF

Koninklijke Philips N.V. manufactures and sells many products targeted at consumers, which, like any electronic apparatus, in general have the ability to emit and receive electromagnetic signals.

One of Philips' leading Business Principles is to take all necessary health and safety measures for our products, to comply with all applicable legal requirements and to stay well within the EMF standards applicable at the time of producing the products.

Philips is committed to develop, produce and market products that cause no adverse health effects. Philips confirms that if its products are handled properly for their intended use, they are safe to use according to scientific evidence available today.

Philips plays an active role in the development of international EMF and safety standards, enabling Philips to anticipate further developments in standardization for early integration in its products.

Recycling



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

สารบัญ

1	ข้อสำคัญ	20
	ปลอดภัย	20
2	เครื่องฟอกอากาศของคุณ	21
	ในชุดขายผลิตภัณฑ์มีอะไรบ้าง	21
3	เริ่มต้นใช้งาน	22
	ติดตั้งแผ่นกรอง	22
4	ใช้เครื่องฟอกอากาศ	24
	ทำความเข้าใจกับ Healthy	
	Air Protect Alert	
	(การเตือนปกป้องอากาศ)	24
	เปิดหรือปิดการใช้งาน	24
	เปลี่ยนความเร็วพัดลม	25
	โหมดการทำงาน	25
	ตั้งตัวจับเวลา	26
5	ทำความสะอาด	
	เครื่องฟอกอากาศ	
	ของคุณ	27
	ทำความสะอาดเครื่อง	
	ฟอกอากาศ	27
	ทำความสะอาดตัวกรองผงถ่าน	
	กัมมันต์	27
6	เปลี่ยนแผ่นกรอง	29
	เปลี่ยนตัวกรองผงถ่านกัมมันต์	
	และแผ่นกรอง HEPA	29
	รีเซ็ตตัวนับอายุการใช้งาน	
	แผ่นกรอง	31
7	การแก้ไขปัญหา	32
8	การรับประกันและบริการ	33
	สั่งซื้อชิ้นส่วนหรืออุปกรณ์เสริม	33
9	ประกาศ	34
	คลื่นแม่เหล็กไฟฟ้า (EMF)	34
	การปฏิบัติตามมาตรฐาน EMF	34
	การรบกวน	34

1 ข้อสำคัญ

ปลอดภัย

โปรดอ่านคู่มือการใช้งานอย่างละเอียดก่อนใช้เครื่อง และเก็บไว้เพื่ออ้างอิงต่อไป

อันตราย

- ห้ามไม่ให้น้ำหรือของเหลวอื่นๆ หรือน้ำยา ที่ติดไฟได้ เข้าเครื่องเป็นอันตราย เพื่อหลีกเลี่ยง ไฟฟ้าช็อตและ/หรือการเกิดเพลิงไหม้
- ห้ามใช้น้ำ ของเหลวอื่นๆ หรือน้ำยาทำความสะอาด (ที่ติดไฟได้) ทำความสะอาดเครื่อง เพื่อหลีกเลี่ยง ไฟฟ้าช็อตและ/หรือการเกิดเพลิงไหม้

คำเตือน

- ก่อนเสียบปลั๊กเครื่อง โปรดตรวจสอบแรงดันไฟ ที่แสดงไว้ด้านล่างหรือด้านหลังของเครื่องว่าตรงกับ แรงดันไฟที่ใช้ภายในบ้านหรือไม่
- หากสายไฟชำรุด คุณต้องให้ช่างผู้ชำนาญของ Philips, ศูนย์บริการที่ได้รับอนุญาตจาก Philips หรือผู้ที่ผ่านการฝึกอบรม ดำเนินการเปลี่ยนให้ เพื่อหลีกเลี่ยงอันตรายที่อาจเกิดขึ้น
- ห้ามใช้งานเครื่องหากปลั๊กไฟ สายไฟ หรือตัวเครื่อง เกิดการชำรุด
- เด็กอายุ 8 ปีและมากกว่า และผู้ที่มีสภาพร่างกาย ไม่สมบูรณ์หรือสภาพจิตใจ ไม่ปกติ หรือขาด ประสบการณ์และความรู้ความเข้าใจสามารถใช้งาน เครื่องนี้ได้ โดยต้องอยู่ในการควบคุมดูแลหรือ ได้รับคำแนะนำในการใช้งานที่ปลอดภัยและเข้าใจ ถึงอันตรายที่เกี่ยวข้องในการใช้งาน ห้ามเด็กเล่น เครื่อง ห้ามให้เด็กทำความสะอาดและดูแลรักษา เครื่องโดยปราศจากการควบคุมดูแล
- ห้ามวางสิ่งของปิดกั้นทางลมเข้าและทางลมออก

ข้อควรระวัง


- อุปกรณ์นี้ไม่ใช่อุปกรณ์ทดแทนการถ่ายเทอากาศ ให้ดีขึ้น การทำความสะอาดด้วยระบบสูญญากาศ หรือ การใช้พัดลมดูดอากาศขณะปรุงอาหาร
- หากต้องเข้ากับเตารีดที่ใช้ในการจ่ายไฟให้เครื่อง ไว้ไม่ดี ปลั๊กของเครื่องจะร้อน ตรวจสอบให้แน่ใจว่า คุณเสียบปลั๊กเครื่องเข้ากับเตารีดแล้ว
- วางและใช้งานอุปกรณ์บนพื้นที่แห้ง มั่นคง เรียบ และมีพื้นผิวในแนวราบเสมอกันเสมอ
- เว้นระยะด้านหลังและทั้งสองด้านของเครื่อง อย่างน้อย 20 ซม. และเว้นระยะเหนือเครื่อง 30 ซม.
- ห้ามวางทุกลิ่งที่ด้านบนของเครื่อง และห้ามนั่ง บนเครื่อง
- ห้ามวางเครื่องไว้ใต้เครื่องปรับอากาศ ทั้งนี้เพื่อ ป้องกันการกลั่นตัวเป็นหยดน้ำหยดลงบนตัวเครื่อง
- ตรวจสอบให้แน่ใจว่าประกอบแผ่นกรองทั้งหมด เข้าที่เรียบร้อยแล้วก่อนทำการเปิดสวิตช์ใช้งาน
- โปรดใช้เฉพาะแผ่นกรองแท้ของ Philips ที่ผลิตมา เพื่อใช้งานกับเครื่องนี้เท่านั้น อย่าใช้แผ่นกรองอื่น
- หลีกเลี่ยงการกระแทกเครื่อง โดยเฉพาะอย่างยิ่ง ทางลมเข้าและออก ด้วยวัตถุที่มีความแข็ง
- ควรยกหรือเคลื่อนย้ายเครื่องโดยจับด้ามจับที่อยู่ ด้านหลังของตัวเครื่อง
- อย่าสูดดมหรือสูดดมใดๆ เข้าไปในทางลมออก
- ห้ามใช้เครื่องนี้หากคุณมีการใช้ยาใส่แมลงแบบ ควินายในอาคาร หรือห้ามใช้ในสถานที่ๆ มีเศษ ตกค้างที่มีลักษณะเหมือนน้ำมัน บริเวณที่มีการ จุดจุด หรือควันของสารเคมี
- ห้ามใช้เครื่องใกล้กับอุปกรณ์ที่เกี่ยวข้องกับก๊าซเชื้อเพลิง อุปกรณ์ให้ความร้อน หรือเตาไฟ
- ปิดเครื่องทุกครั้งหลังใช้งานและก่อนทำความสะอาดเครื่อง
- ห้ามใช้งานเครื่องในห้องที่มีการเปลี่ยนแปลงของ อุณหภูมิอย่างมาก เนื่องจากภายในเครื่องอาจ ก่อให้เกิดการกลั่นตัวเป็นหยดน้ำได้
- เพื่อเป็นการป้องกันการรบกวน ควรวางเครื่อง ให้ห่างจากเครื่องใช้ไฟฟ้าที่ใช้คลื่นวิทยุทางอากาศ เช่น โทรศัพท์ วิทยุ และนาฬิกาที่ควบคุมด้วย คลื่นวิทยุอย่างน้อย 2 เมตร
- เครื่องนี้เหมาะสำหรับการใช้งานในครัวเรือน ภายใต้อากาศแวดล้อมการทำงานที่ปกติเท่านั้น
- ห้ามใช้งานเครื่องนี้ในที่เปียกชื้นหรือในที่ๆ มีอุณหภูมิสูง เช่น ห้องน้ำหรือห้องครัว
- เครื่องจะไม่จัดคาร์บอนมอนอกไซด์ (CO) หรือ เรดอน (Rn) และไม่สามารถใช้เป็นอุปกรณ์ ปลอดภัยในกรณีที่เกิดอุบัติเหตุที่มีการเผาไหม้ และมีสารเคมีที่เป็นอันตราย

2 เครื่องฟอกอากาศ ของคุณ

ขอแสดงความยินดีที่คุณเลือกซื้อผลิตภัณฑ์ของเรา
และยินดีต้อนรับสู่ Philips
เพื่อให้คุณได้รับประโยชน์อย่างเต็มที่จากบริการ
ที่ Philips มอบให้ โปรดลงทะเบียนผลิตภัณฑ์ของคุณ
ที่ www.philips.com/welcome
อ่านคู่มือการใช้งานนี้โดยละเอียดก่อนการติดตั้ง
และใช้งานเครื่อง และเก็บไว้เพื่ออ้างอิงต่อไป

ในชุดขายผลิตภัณฑ์มีอะไรบ้าง

ตรวจสอบและระบุอุปกรณ์ที่ให้มาภายในกล่องของคุณ:



แผ่นกรอง 4: แผ่นกรอง
HEPA (AC4104)

แผ่นกรอง 3: ตัวกรองผงถ่าน
กัมมันต์ (AC4103)

แผ่นกรอง 1 และ 2 ใช้สำหรับเครื่องฟอกอากาศ
Philips อื่นๆ



คู่มือการใช้งาน



รับประกัน



คู่มือเริ่มต้นใช้งานอย่างย่อ

3 เริ่มต้นใช้งาน

ติดตั้งแผ่นกรอง

เครื่องฟอกอากาศมาพร้อมกับแผ่นกรองทั้งหมดที่ติดตั้งพอดีอยู่แล้วใน แต่คุณต้องนำบรรจุภัณฑ์ของแผ่นกรองออกก่อนการใช้งานเครื่อง ถอดแผ่นกรองทั้งหมดออก นำบรรจุภัณฑ์ออก จากนั้นใส่แผ่นกรองกลับเข้าไปในเครื่องฟอกอากาศตามที่อธิบายด้านล่าง



เคล็ดลับ


- เมื่อถอดหรือใส่แผ่นกรอง ให้วางเครื่องฟอกอากาศชิดฝาผนัง เพื่อเพิ่มความมั่นคง




หมายเหตุ

- เลือกแผ่นกรองในตำแหน่งที่ต้องการ


- 1 วางนิ้วของคุณไว้ที่แผงด้านบน และค่อยๆ ดึงส่วนบนของแผงด้านหน้าเข้าหาตัว (1)
- 2 ยกแผงออกจากข้อเกี่ยวที่ด้านล่างของเครื่องฟอกอากาศ (2)




- 3 ถอดแผ่นกรองทั้งหมดออกจากเครื่องฟอกอากาศ



- 4 นำบรรจุภัณฑ์ทั้งหมดออกจากแผ่นกรอง




- 5 ใส่แผ่นกรองกลับเข้าไปในเครื่องฟอกอากาศ



หมายเหตุ

- ตรวจสอบให้แน่ใจว่าหันด้านที่มีป้ายเข้าหาตัว และป้ายนั้นอยู่ด้านล่างของแผ่นกรอง

- 6 ในการประกอบแผงด้านหน้า ให้เสียบขอก๊วยด้านล่างเข้ากับด้านล่างของเครื่องฟอกอากาศก่อน (1) จากนั้น ให้กดแผงเข้ากับตัวเครื่องฟอกอากาศ(2)



4 ใช้เครื่องฟอกอากาศ

ทำความเข้าใจกับ Healthy Air Protect Alert (การเตือนปกป้องอากาศดี)

เครื่องฟอกอากาศนี้มาพร้อมกับ Healthy Air Protect Alert (การเตือนปกป้องอากาศดี) เพื่อให้แน่ใจว่าแผ่นกรองอยู่ในสภาพที่เหมาะสมเมื่อเครื่องฟอกอากาศทำงาน ไฟแสดงการเปลี่ยนแผ่นกรอง (๘) จะแจ้งว่าต้องมีการเปลี่ยนแผ่นกรอง


Healthy Air Protect Alert (การเตือนปกป้องอากาศดี) ให้ปฏิบัติตาม

ไฟแสดงการเปลี่ยนแผ่นกรอง ๘ กระพริบ ซึ่งจะเป็นเช่นนี้ประมาณ 2 สัปดาห์	คุณจะมีเวลา 2 สัปดาห์ในการเปลี่ยนตัวกรองผงถ่านกัมมันต์และแผ่นกรอง HEPA
ไฟแสดงการเปลี่ยนแผ่นกรอง ๘ ติดสว่างต่อเนื่อง	เปลี่ยนตัวกรองผงถ่านกัมมันต์และแผ่นกรอง HEPA ทันที


เปิดหรือปิดการใช้งาน

- 1 เสียบปลั๊กเครื่องฟอกอากาศเข้ากับแหล่งจ่ายไฟ
↳ ไฟทุกดวงจะติดสองครั้ง จากนั้นไฟจะดับอีกครั้ง


แผงควบคุม



- 2 กดปุ่ม ๐ เพื่อเปิดเครื่องฟอกอากาศ
↳ ไฟแสดงการเปิดเครื่อง [๑] บนแผงควบคุมจะสว่าง



- 3 กดปุ่ม ๐ เพื่อปิดเครื่องฟอกอากาศ



เปลี่ยนความเร็วพัดลม


คุณสามารถเลือกความเร็วพัดลมที่ต้องการได้




หมายเหตุ

- เมื่อเลือกความเร็วพัดลม คุณยังสามารถใช้ฟังก์ชันตัวจับเวลาได้อีกด้วย (ดู 'ตั้งตัวจับเวลา') ในกรณีนี้ ไฟ ๑ ดวงใดดวงหนึ่ง (๑, ~ และ ≈) และไฟ ๑ ดวงใดดวงหนึ่ง (14 หรือ 8) จะสว่าง

1 กดปุ่ม ๑ เพื่อเปิดเครื่อง




2 กดปุ่ม ๑ หนึ่งครั้งหรือหลายครั้งเพื่อเลือกความเร็วพัดลมที่ต้องการ (๑, ~ หรือ ≈)




โหมดการทำงาน

ในโหมดการทำงาน เครื่องฟอกอากาศจะทำงานอย่างเงียบเพื่อไม่ให้รบกวนคุณยามหลับพักผ่อน

1 กดปุ่ม ๑ เพื่อเปิดเครื่องฟอกอากาศ



2 กดปุ่ม ๑ เพื่อเลือกโหมดการทำงาน
→ ไฟ ๑ จะเปิดขณะที่ ๑ ปิดลง



หากต้องการเปลี่ยนความเร็วพัดลมเป็นระดับอื่น ให้กดปุ่ม ๑


ตั้งตัวจับเวลา

คุณสามารถปล่อยให้เครื่องฟอกอากาศทำงานตามเวลาที่ตั้งไว้ในหน่วยชั่วโมงด้วยฟังก์ชันตัวจับเวลา เมื่อพ้นเวลาที่ตั้งไว้ เครื่องฟอกอากาศจะปิดโดยอัตโนมัติ


คุณสามารถใช้ฟังก์ชันตัวจับเวลาในสถานการณ์ต่อไปนี้:

สถานการณ์	คุณ将会เห็น
เลือกความเร็วพัดลมด้วยตนเอง (ดู 'ด้วยตนเอง')	ไฟ ๐ ดวงใดดวงหนึ่ง (☾, ~ หรือ ≈) และไฟ ๐ ดวงใดดวงหนึ่ง (๑.4 หรือ 8) จะติดสว่าง

1 กดปุ่ม ๐ เพื่อเปิดเครื่องฟอกอากาศ



2 กดปุ่ม ๐ เพื่อเปิดใช้งานตัวจับเวลา
» ไฟ ๐ (๑.4 หรือ 8) จะติดสว่าง



3 กดปุ่ม ๐ ซ้ำๆ เพื่อเลือกจำนวนชั่วโมงที่คุณต้องการให้เครื่องฟอกอากาศทำงาน ไฟ ๐ ที่สอดคล้องกัน (๑.4 หรือ 8) จะติดสว่าง หากต้องการเปิดใช้งานฟังก์ชันตัวจับเวลา ให้กดปุ่ม ๐ ซ้ำๆ จนกว่าไฟ ๐ (๑.4 หรือ 8) จะดับลง

5 ทำความสะอาดเครื่องฟอกอากาศของคุณ



หมายเหตุ

- ถอดปลั๊กออกทุกครั้งก่อนทำความสะอาดเครื่องฟอกอากาศ
- ห้ามนำเครื่องฟอกอากาศจุ่มลงในน้ำหรือของเหลวอื่นๆ
- ห้ามใช้สารทำความสะอาดที่มีฤทธิ์กัดกร่อน รุนแรง หรือติดไฟได้ เช่น สารฟอกขาว หรือแอลกอฮอล์เพื่อทำความสะอาดส่วนต่างๆ ของเครื่องฟอกอากาศ
- แผ่นกรองเครื่องฟอกอากาศ ไม่สามารถล้างทำความสะอาดได้

ทำความสะอาดเครื่องฟอกอากาศ

ทำความสะอาดด้านในและด้านนอกของตัวเครื่องฟอกอากาศเป็นประจำเพื่อป้องกันการสะสมของฝุ่น

- 1 เช็ดฝุ่นด้วยผ้านุ่มที่แห้งจากตัวเครื่องฟอกอากาศ
- 2 ใช้ผ้านุ่มที่แห้งทำความสะอาดทางลมเข้าและทางลมออก

ทำความสะอาดตัวกรองผงถ่านกัมมันต์


ตัวกรองผงถ่านกัมมันต์นี้จะจับอนุภาคในอากาศ เช่น ขุยผ้า ฝุ่น เส้นผม/ขน และขนสัตว์ อีกทั้งยังช่วยกำจัดกลิ่น




หมายเหตุ

- ตัวกรองผงถ่านกัมมันต์ไม่สามารถล้างทำความสะอาดหรือทำความสะอาดด้วยเครื่องดูดฝุ่นได้
- ทำความสะอาดตัวกรองผงถ่านกัมมันต์ทุก 6 สัปดาห์เพื่อให้แน่ใจว่าเครื่องฟอกอากาศจะทำงาน ได้ดีที่สุด


1 ปิดเครื่องฟอกอากาศและถอดปลั๊ก




2 วางนิ้วของคุณ ไว้ที่แผงด้านบน และค่อยๆ ดึงส่วนบนของแผงด้านหน้าเข้าหาตัว (1) ยกแผงออกจากขอกเกี่ยวที่ด้านล่างของเครื่องฟอกอากาศ (2)




3 ถอดตัวกรองผงถ่านกัมมันต์ออก




- 4 ทำความสะอาดตัวกรองผงถ่านกัมมันต์ด้วยแปรงขนนุ่มเพื่อกำจัดฝุ่น



- 5 ใส่ตัวกรองผงถ่านกัมมันต์กลับเข้าไปในเครื่องฟอกอากาศ



- 6 ในการประกอบแผงด้านหน้า ให้เสียบขอก๊วยด้านล่างเข้ากับด้านล่างของเครื่องฟอกอากาศก่อน (1) จากนั้น ให้กดแผงเข้ากับตัวเครื่องฟอกอากาศ(2)



6 เปลี่ยนแผ่นกรอง

ไฟแสดงการเปลี่ยนแผ่นกรอง () จะแจ้งว่า
ต้องมีการเปลี่ยนแผ่นกรอง

เปลี่ยนตัวกรองผงถ่านกัมมันต์ และแผ่นกรอง HEPA


หมายเหตุ

- ตัวกรองผงถ่านกัมมันต์และแผ่นกรอง HEPA ไม่สามารถ
ล้างทำความสะอาดหรือทำความสะอาดด้วยเครื่องดูดฝุ่นได้

เปลี่ยนทั้งตัวกรองผงถ่านกัมมันต์และแผ่นกรอง HEPA
เมื่อไฟ () เริ่มกะพริบ ซึ่งจะเป็นเช่นนี้ประมาณ

2 สัปดาห์
เมื่อคุณไม่ได้เปลี่ยนแผ่นกรองภายในเวลาที่กำหนด

→ ไฟ () จะสว่างอย่างต่อเนื่อง



ในโหมดการทำงาน ไฟ () จะเริ่มกะพริบแต่เป็น
แสงสลัว ให้เปลี่ยนทั้งตัวกรองผงถ่านกัมมันต์และ
แผ่นกรอง HEPA ซึ่งจะเป็นเช่นนี้ประมาณ 2 สัปดาห์

เมื่อคุณไม่ได้เปลี่ยนแผ่นกรองภายในเวลาที่กำหนด

→ ไฟ () สว่างแต่เป็นแสงสลัวอย่างต่อเนื่อง


เคล็ดลับ

- เมื่อถอดหรือใส่แผ่นกรอง ให้วางเครื่องฟอกอากาศขัดผ้าแห้ง
เพื่อเพิ่มความสะดวก


หมายเหตุ

- เลือกแผ่นกรองในตำแหน่งที่ถูกต้อง
- ตรวจสอบให้แน่ใจว่าคุณใส่แผ่นกรองตามลำดับแผ่นกรอง
HEPA และตัวกรองผงถ่านกัมมันต์
- ตรวจสอบให้แน่ใจว่าด้านหลังที่มีป้ายเข้าหาตัว และป้ายนั้น
อยู่ด้านล่างของแผ่นกรอง


1 ปิดเครื่องฟอกอากาศและถอดปลั๊ก



2 วางนิ้วของคุณไว้ที่แผงด้านบน และค่อยๆ ดึง ส่วนบนของแผงด้านหน้าเข้าหาตัว (1) ยกแผง ออกจากขอเกี่ยวที่ด้านล่างของ เครื่องฟอกอากาศ (2)




- 3 ถอดแผ่นกรองออกตามที่ระบุในแถบป้ายบนแผ่นกรอง ถือแผ่นกรองทั้งสองข้าง แล้วค่อยๆ นำไปทิ้งในถังขยะ




หมายเหตุ

- อย่าสัมผัสพื้นผิวแผ่นกรองที่เป็นรอยจีบ หรือสุดคมแผ่นกรอง เนื่องจากแผ่นกรองมีมลพิษที่สะสมจากอากาศ
- ล้างมือให้สะอาดหลังจากนำแผ่นกรองที่ใช้แล้วไปทิ้ง


- 4 นำบรรจุภัณฑ์ทั้งหมดออกจากแผ่นกรองใหม่




- 5 ใส่แผ่นกรอง HEPA ในเครื่องฟอกอากาศก่อน



- 6 ใส่ตัวกรองผงถ่านกัมมันต์ใหม่ลงในเครื่องฟอกอากาศ



- 7 ในการประกอบแผงด้านหน้า ให้เสียบขอเกี่ยวด้านล่างเข้ากับด้านล่างของเครื่องฟอกอากาศก่อน (1) จากนั้น ให้กดแผงเข้ากับตัวเครื่องฟอกอากาศ(2)




- 8 รีเซ็ตอายุการใช้งานของตัวกรองผงถ่านกัมมันต์ และแผ่นกรอง HEPA (ดูรีเซ็ตตัวนับอายุการใช้งานแผ่นกรอง)

รีเซ็ตตัวนับอายุการใช้งาน แผ่นกรอง


เมื่อเปลี่ยนแผ่นกรอง สิ่งสำคัญคือคุณจะต้องรีเซ็ตตัวนับอายุการใช้งานแผ่นกรองหลังจากนั้นด้วย วิธีนี้จะช่วยให้เครื่องฟอกอากาศยังคงสอดคล้องกับอายุการใช้งานของแผ่นกรอง หลังจากที่คุณเปลี่ยนแผ่นกรองแล้ว ให้รีเซ็ตเวลาของแผ่นกรอง

1 ปิดเครื่องฟอกอากาศและถอดปลั๊ก




2 เปลี่ยนแผ่นกรองเครื่องฟอกอากาศ (ดู 'เปลี่ยนแผ่นกรอง')

3 เสียบปลั๊กเข้ากับเต้ารับและเปิดเครื่อง ฟอกอากาศอีกครั้ง



4 กดปุ่ม ๑ ค้างไว้เป็นเวลา 2 วินาที






หมายเหตุ

- รีเซ็ตเครื่องฟอกอากาศเมื่อเสียบปลั๊กและเปิดเครื่องแล้ว
- เปลี่ยนแผ่นกรองเมื่อคุณเห็นไฟ ๑ เริ่มกะพริบเท่านั้น

7 การแก้ไขปัญหา

ในบทนี้ เราได้รวบรวมปัญหาต่างๆ ที่อาจเกิดขึ้นกับเครื่องฟอกอากาศได้ หากคุณไม่สามารถแก้ปัญหาด้วยข้อมูลด้านล่างได้ กรุณาติดต่อศูนย์บริการลูกค้าในประเทศของคุณ

ปัญหา	วิธีแก้ไขที่สามารถทำได้
ไฟ  กระพริบ	แผ่นกรองเต็มแล้ว เปลี่ยนแผ่นกรองและรีเซ็ตเครื่องฟอกอากาศ
ไม่มีอากาศออกจากทางลมออก	เครื่องฟอกอากาศไม่ได้เชื่อมต่อกับแหล่งจ่ายไฟ เสียบปลั๊กเครื่องฟอกอากาศเข้ากับแหล่งจ่ายไฟและเปิดเครื่อง
อากาศหมุนเวียนที่ออกมาจากทางลมออกเบาลงกว่าที่เคย อย่างเห็นได้ชัด	โปรดตรวจสอบว่าคุณได้แกะวัสดุบรรจุภัณฑ์ทั้งหมดที่ห่อแผ่นกรองออก
คุณภาพของอากาศยังไม่ดีขึ้น แม้ว่าเครื่องฟอกอากาศจะทำงานมาเป็นเวลานานแล้ว	วางแผ่นกรองแผ่นใดแผ่นหนึ่งไม่เข้าที่ในเครื่องฟอกอากาศ ตรวจสอบให้แน่ใจว่าติดตั้งแผ่นกรองทั้งหมดอย่างถูกต้องเรียงตามลำดับโดยเริ่มจากด้านในสุด ดังนี้: 1) แผ่นกรอง HEPA 2) ตัวกรองผงถ่านกัมมันต์
เครื่องฟอกอากาศมีเสียงดังมาก	<ul style="list-style-type: none">โปรดตรวจสอบว่าคุณได้แกะวัสดุบรรจุภัณฑ์ทั้งหมดที่ห่อแผ่นกรองออกหากเครื่องยังมีเสียงดังเกินไป คุณสามารถเปลี่ยนความเร็วพัดลมไปที่ระดับความเร็วพัดลมที่ต่ำลงได้
เครื่องฟอกอากาศยังแสดงสัญญาณว่าฉันต้องเปลี่ยนแผ่นกรอง แต่ฉันได้เปลี่ยนไปแล้ว	คุณอาจไม่ได้กดปุ่มรีเซ็ตแผ่นกรองให้ดี เสียบปลั๊กเครื่องฟอกอากาศ กดปุ่ม  จากนั้นกดปุ่ม  ค้างไว้ 2 วินาที

8 การรับประกัน และบริการ

หากคุณต้องการทราบข้อมูลหรือหากมีข้อสงสัย โปรดเข้าชมเว็บไซต์ของ Philips ได้ที่ www.philips.com หรือติดต่อศูนย์บริการดูแลลูกค้าของ Philips ในประเทศของคุณ (หมายเลขโทรศัพท์ของศูนย์บริการฯ อยู่ในเอกสารแผ่นพับเกี่ยวกับการรับประกันทั่วโลก) หากในประเทศของคุณไม่มีศูนย์บริการลูกค้า โปรดติดต่อตัวแทนจำหน่ายผลิตภัณฑ์ Philips ในประเทศ

สั่งซื้อชิ้นส่วนหรืออุปกรณ์เสริม

หากคุณต้องเปลี่ยนชิ้นส่วนหรือต้องการสั่งซื้อชิ้นส่วนเพิ่มเติมโปรดไปที่ตัวแทนจำหน่ายของ Philips หรือไปที่ www.philips.com/support หากคุณมีปัญหาในการรับชิ้นส่วน โปรดติดต่อศูนย์บริการดูแลลูกค้าในประเทศของคุณ (หมายเลขโทรศัพท์ของศูนย์บริการฯ อยู่ในเอกสารแผ่นพับเกี่ยวกับการรับประกันทั่วโลก)

9 ประกาศ

คลื่นแม่เหล็กไฟฟ้า (EMF)

ผลิตภัณฑ์ของ Philips นี้เป็นไปตามมาตรฐานและกฎข้อบังคับด้านคลื่นแม่เหล็กไฟฟ้าที่มีทุกประการ

การปฏิบัติตามมาตรฐาน EMF

Koninklijke Philips N.V. ผลิตและจำหน่ายผลิตภัณฑ์จำนวนมากที่มีผู้บริโภคเป็นกลุ่มเป้าหมาย โดยผลิตภัณฑ์ดังกล่าวสามารถปล่อยและรับคลื่นแม่เหล็กไฟฟ้าได้เช่นเดียวกันกับอุปกรณ์อิเล็กทรอนิกส์ทั่วไป

หนึ่งในหลักการดำเนินธุรกิจที่สำคัญของ Philips คือการคำนึงถึงสุขภาพและความปลอดภัยสำหรับผลิตภัณฑ์ของคุณ เพื่อให้สอดคล้องกับกฎหมายและมาตรฐาน EMF ซึ่งต้องใช้ในช่วงเวลาการผลิตสำหรับผลิตภัณฑ์นั้นๆ

Philips มุ่งมั่นที่จะพัฒนา ผลิต และจำหน่ายผลิตภัณฑ์ที่ไม่มีผลในเชิงลบต่อสุขภาพ Philips ยืนยันว่าหากใช้งานผลิตภัณฑ์ตามวัตถุประสงค์อย่างเหมาะสม ผลิตภัณฑ์เหล่านั้นจะปลอดภัยต่อการใช้ตามหลักฐานที่ผ่านการทดสอบ

Philips มีบทบาทสำคัญในการพัฒนา EMF และมาตรฐานความปลอดภัยสากล ซึ่งทำให้ Philips มีส่วนร่วมพัฒนามาตรฐานเพื่อนำมาใช้กับผลิตภัณฑ์

การรีไซเคิล



ห้ามทิ้งผลิตภัณฑ์พร้อมกับขยะจากครัวเรือนโปรดศึกษาข้อบังคับท้องถิ่นว่าด้วยการแยกเก็บผลิตภัณฑ์ไฟฟ้าและอิเล็กทรอนิกส์ การทิ้งผลิตภัณฑ์ที่เสื่อมสภาพอย่างถูกวิธีจะช่วยป้องกันไม่ให้เกิดผลกระทบในทางลบต่อสิ่งแวดล้อมและสุขภาพได้

